


Innoseal® Bag Sealer - Implementation Plan Directions for Use

The **Innoseal® Bag Sealer** is an easy to open tamper evident bag closure system which packages in less time and provides a virtual airtight seal to ensure product freshness. Please follow the implementation steps below to begin using the **Innoseal® Bag Sealer**.



Implementation Steps

Please visit our website at <https://www.innoseal.com/about/videos/> for **instructional videos**.

When you receive your **Innoseal® Bag Sealer**.

- You will notice that the **Innoseal® Bag Sealer** has been pre-loaded with a roll of **Innoseal®** quality paper and tape.
- Run a test bag through the **Innoseal® Bag Sealer**, to verify that the paper and tape has not shifted during shipment to you.
- With a bag in hand, twist the excess around the neck of the bag (approximately 3 times) and confidently run the bag through the **Innoseal® Bag Sealer**, from top to bottom, in one complete motion.
- If the paper/tape seal does not hold, follow the loading instructions below and retest. Your first seal will be lost and the second pass through the **Innoseal® Bag Sealer** will be a quality seal.
- **To LOAD the Innoseal® Bag Sealer, please follow the diagram below.**

How to replace the refill:



1. Load tape sticky side up - tape end hangs outside the casing
2. Paper travels through the paper channel into one of the wheel ports
3. Advance the wheel counter clockwise until the paper fits into one of the ports
4. Close the Innoseal® Bag Sealer

The Innoseal® Bag Sealer should be cleaned after each roll of tape and paper refill is used (before you reload). You may use an alcohol swab or warm soapy cloth to remove any build up. Remove the wheel and wipe clean, then insert wheel, tape and paper to begin using again.

For assistance, please call Innoseal® Systems at 1-866-958-4666.